


80G FM Radar Level Meter

Commissioning instructions



Key function description:

There are 4 buttons on the instrument panel, through which the instrument can be debugged. The language of the debugging menu is optional. After debugging, the LCD screen displays the measured value, and the measured value can be clearly read through the glass window.



1. LCD display

2. Buttons

Key Functions:

[**OK**] key

- Enter programming state;
- Confirm programming items;
- Confirm parameter modification.

[**▲**] key


- Select programming items;
- Modify the parameter value;
- Air-to-air/material-high switching during operation;

[**↻**] key

- Select programming items;
- Select edit parameter bit;
- Content display of parameter items;

[**BK**] key



- Exit programming state;
- Return to the previous menu;
- During operation, the measured value/echo waveform is switched.



Programming instructions

Programming menu structure

We can use the four buttons on the panel to realize the parameter setting, debugging and testing functions of the instrument.

The menu structure can be found in the final table. In the figure, the transition to the right horizontal arrow is realized by the **OK** key; the downward arrow transition is realized by the  key; the upward arrow transition is realized by the  key; and the **BK** key realizes the horizontal arrow to the left.

Programming submenu

basic settings

The basic settings include the basic parameters of the instrument: high and low adjustment, range, blind range, material properties, range offset, current output and track setting.

Display

The display is to set the language, curve range and unit of the instrument.

Advanced settings

Advanced settings includes more specialized content of meter, clutter update, no target set, damp time, damp coeff.

Service

Services include password, current emulation, current bias, factory Settings restoration, firmware updates.

Information



The information includes the factory date, serial number, and version number of the instrument.

Programming method



When the meter is in the running state, press **OK** to enter the programming state and display the programming main menu. After editing each parameter, you need to confirm with **OK**, otherwise the editing is invalid. After finishing editing, press the **BK** to exit the programming state and return to the running state. At any time during programming, you can press **BK** to abandon programming and exit the parameter item programming state.

Optional parameter programming

Character/number parameter programming

When the menu enters the character/number programming state, the first digit of the edited parameter is reversed to black. At this time, you can press  to change the character/number until the desired character/number, press , the character bit/number Anti-black, you can program other bits. After programming, press **OK** to confirm programming.


Optional parameter programming

Optional parameters means that there are several selected parameter items for the user to choose. Use the  or  to point the arrow to the desired parameter item, and press the **OK** to confirm the programming.

Programming menu description

The basic settings include the settings of the main instrument parameters, such as high and low adjustment, range, material properties, blind range, etc. In the running state, press the **OK** button to enter the programming state, the LCD displays the main menu

1 Basic Settings



When the arrow points to the basic settings, press **OK** to enter the basic settings submenu

► Min.-Max. adj.
Range
Near blanking
Detect scene

Range adj.
Current set
Track set
Gain set

1.1 Min.-Max. adj.

Min -Max adj is used to set the range, which together determine the ratio of the linear correspondence between current outputs.

In the sub-menu of basic settings, when the arrow points to high-low adjustment, press **OK** key to enter the corresponding value of Min adjustment, the LCD display

Low Pos (m)
005.000
High Pos (m)
000.300

1.2 Range

Refer to the character/digit parameter programming method in the preceding parameter editing method, edit the distance value corresponding to the low level adjustment and the distance value corresponding to the high level adjustment, press **OK** key to confirm the modification after editing, and press **BK** key to abandon the programming.

For accurate measurement, it is necessary to set the measuring range.

When the arrow points to high-low adjustment, press **↶** to move to range, press **OK** to enter range setting menu, the LCD displays

Range (m)
006.000

At this time, the cursor is on the first digit field of the parameter, press **↶** key to move the cursor position, press **↑** key to modify the parameter value, press **OK** key to confirm the modification, press **BK** key to abandon the programming

1.3 Near blanking

When there is a fixed obstacle near the surface of the sensor that interferes with the measurement, and the maximum material height will not reach the obstacle, the setting function of the near blanking range can be used to avoid measurement errors.

When the arrow points to range, press **↶** to move to blind range, press **OK** to enter the setting menu, the LCD displays

Blind Range (m)
00.100


At this time, the cursor is on the first digit field of the parameter, press **↶** key to move the cursor position, press **↑** key to modify the parameter value, press **OK** key to confirm the modification, press **BK** key to abandon the programming



1.4 Detect scene

Detect scene menu is used to select solid or liquid or stir, so as to further determine other properties of the material that affect the measurement.

When the arrow points to blind range, press to move to material properties(cuurent set), press to enter the setting menu, the LCD displays




use and keys to select the material property as liquid, solid or stir, After editing, press to confirm.

1.5 Range adj.

Range adj is used to modify the measurement error, and its value is the difference between the actual air height value and the displayed air height value.


When the arrow points to material properties(Cuurent Set), press to move to distance offset, press to enter the setting menu, the LCD displays



At this time, the cursor is on the first digit field of the parameter, press key to move the cursor position, press key to modify the parameter value, press key to confirm the modification, press key to abandon the programming

1.6 Current set

When the arrow points to range adj, press to move to Current set, press to enter current output menu setting, the LCD display







use the to select, press the to confirm.


1.7 Track set

Track set is to control the echo tracking by setting the tracking width and holding time. It can be kept for a period of time within the setting range to prevent sudden changes when the radar collects values.





When the arrow points to current output(Detect Secene), press to move to follow wave settings(Track Set), press to enter the menu , the LCD display



Press  or  to select Yes or No. When yes, press  to enter tracking width and holding time setting menu, LCD display






Width (m)
0.00
Time Span (s)
0000

At this time, the cursor is on the first digit field of the parameter, press  key to move the cursor position, press  key to modify the parameter value, press  key to confirm the modification, press  key to abandon the programming





1.8 Gain set

Changing the gain value will change the size of the echo signal, but also the size of the noise. Choose different gain values according to different working conditions to achieve the most stable measurement. gain modification ranges from 1 to 15dB

When the arrow points to the follow wave setting, press  to move the arrow to the gain setting, press  to enter the gain set menu setting, the LCD display






Gain Set (dB)
01

At this time, the cursor is on the first digit field of the parameter, press  key to move the cursor position, press  key to modify the parameter value, press  key to confirm the modification, press  key to abandon the programming


2 Display


This function is used to program the display mode.

When the LCD displays the main menu, press the  or  to move the arrow to the display options, the LCD displays




Basic Settings
► Display
Advanced Settings
Service

Press  to enter the display menu, LCD display



► Language
Curve range
Unit
Display value




Amp. scope



2.1 Language

This item is used to control the language of the LCD display. When the arrow points to the language, press **OK** to enter the language menu, the LCD display




Press **↺** to select the language type, and press **OK** to confirm.

2.2 Curve Range

Curve range is to display the echo curve within the specified range.


When the arrow points to language, press the **↺** to move to curve range, press **OK** to enter the setting menu, the LCD displays



At this time, the cursor is on the first digit field of the parameter, press **↺** key to move the cursor position, press **↑** key to modify the parameter value, press **OK** key to confirm the modification, press **BK** key to abandon the programming

2.3 Unit

Units are units of distance and bit height. When the arrow points to curve range, press **↺** to move to unit, press **OK** to enter the menu setting, the LCD display




use the **↺** or **↑** to select, press the **OK** to confirm, Press **BK** to give up

2.4 Display value

The display content refers to the distance value or true level value measured by the meter.



When the arrow points to the unit, press the **↺** key to move the arrow to the display content, press the **OK** key to enter the display content menu, the LCD display




use the **↺** or **↑** to select, press the **OK** to confirm, Press **BK** to give up

2.5 Amp. scope





The advanced Settings menu contains more specialized functions.

When the arrow points to the display content, press the  key to move the arrow to the amplitude range, press the  key to enter the amplitude range menu, and the LCD display






```


Min. (dB)
  0 0 0
Max. (dB)
  0 0 0
  
```

At this time, the cursor is on the first digit field of the parameter, press  key to move the cursor position, press  key to modify the parameter value, press  key to confirm the modification, press  key to abandon the programming

3 Adv. settings


The adv. settings menu contains more professional functions.

When the LCD displays the main menu, press  or  to move the arrow to adv. settings, press  to enter the advanced setting, the LCD displays



```

► Clutter Update
  No target set
  DampTime
  DampCoeff
  
```




```

Low DK
First echo
  
```

3.1 Clutter Update


When the arrow points to clutter update, Press  to move to clutter update, press  to enter the menu, LCD display




```

► Threshold
  Local1
  Local2
  Local3
  
```





3.1.1 Threshold Setting

Threshold setting is a uniform setting of the detection threshold within the measurement range. When the arrow points to the threshold setting, press  to enter the threshold setting, the LCD display



```

Threshold (dB)
  0 1
  
```

At this time, the cursor is on the first digit field of the parameter, press  key to move the cursor position, press  key to modify the parameter value, press  key to confirm the modification, press  key to abandon the programming



3.1.2 Local Setting

The local setting is to learn the false echoes in the container containing known obstacles within the specified range to eliminate the influence of fixed obstacles on the measurement. A total of three intervals can be set.

When the arrow points to global reset, press to select local setting 1, local setting 2, local setting 3, press to enter the local setting menu, the LCD displays

Scope(m)
000.0-000.0
Threshold (dB)
05

At this time, the cursor is on the first digit field of the parameter, press key to move the cursor position, press key to modify the parameter value, press key to confirm the modification, press key to abandon the programming

3.2 No target set

No target setting is the setting of the radar output signal when there is no echo signal. When the arrow points to clutter update, press to move to no signal output(No Target Set), press to enter the menu, the LCD display

Output No Target
► Current Value
Full
Empty

Use the key or the key to select no target output value, press the key to confirm the selection, and press the key to abort the programming.

3.3 Damping Time

Damping time is set to the speed at which the radar display value and output signal change, ranging from 0-999.

When the arrow points to no target set , press to point to damping time, press to enter the damping time menu, LCD display

Dampin Time(s)
000





At this time, the cursor is on the first digit field of the parameter, press key to move the cursor position, press key to modify the parameter value, press key to confirm the modification, press key to abandon the programming

3.4 Damping Coeff

The damping coeff is used to set the refresh speed of radar echo curve, which can be set in the range of 0-99

When the arrow points to damping time use  points to damping coeff, press  to enter the menu, the LCD display







At this time, the cursor is on the first digit field of the parameter, press  key to move the cursor position, press  key to modify the parameter value, press  key to confirm the modification, press  key to abandon the programming


3.5 Low DK





Low DK is aimed at the working condition where the dielectric constant of the tested medium is relatively small. The starting and ending values are set to suppress the tank bottom signal generated by radar penetration within this range.

When the arrow points to damping coeff use  points to low DK, press  to enter the menu, the LCD display






You can use the  key or  key to select whether to set low DK. If yes, press  to enter the start value and end value Settings. The LCD displays




At this time, the cursor is on the first digit field of the parameter, press  key to move the cursor position, press  key to modify the parameter value, press  key to confirm the modification, press  key to abandon the programming


3.6 First Echo

First echo is used to collect front-end signals more stably by setting K% value. It is generally used in conditions that are easy to generate multiple echoes. When the arrow points to low DK, press  key. Arrow moves to first echo, press  key to enter first echo menu, LCD display






You can use the key or key to select whether to set first echo. If yes, press to enter the K(%) Settings. The LCD displays



At this time, the cursor is on the first digit field of the parameter, press key to move the cursor position, press key to modify the parameter value, press key to confirm the modification, press key to abandon the programming

4 Service


The service menu contains five options: password, current simulation, current bias, factory setting restoration, and firmware update. When the LCD displays the main menu, press or to move to service, press to enter the menu, the LCD displays



4.1 Password

When modifying the current bias or firmware update, you need to enter the correct password to enter.

When the arrow points to password, press to enter the password menu, the LCD displays




At this time, the cursor is on the first digit field of the parameter, press key to move the cursor position, press key to modify the parameter value, press key to confirm the modification, press key to abandon the programming

4.2 Current Simulation

Current simulation is the simulation output of 4mA and 20mA, which is used to verify whether the current output function of the instrument is normal, and can also be used for system debugging. When the radar works normally, the current simulation option is no.

When the arrow points to current simulation, press **OK** to enter the menu, the LCD displays




Use the **↶** key or the **↑** key to select the current value to be simulated, press the **OK** key to confirm the selection, and press the **BK** key to abandon the programming.

4.3 Current Offset

The current offset is to set the bias for the output current of 4mA and 20mA. This function requires the verification password.


When the arrow points to current simulation, select current bias with **↶**, enter the correct password, and press **OK** to enter the current offset menu, you can modify the output 4mA and 20mA current.




4.4 Reset System

To restore factory Settings is to reset all contents in basic Settings, display units and amplitude ranges, and all contents in advanced Settings

When arrow points to the current offset, press **↶** to move to reset system, press **OK** to enter the menu, the LCD display



Press **↶** or **↑** to select whether to restore the factory settings, and press **OK** to confirm.







4.5 Firmware Update

Firmware update is used for professional engineers to update the firmware of the radar, which can be ignored in normal use.



5 Information


The information is to check some basic information of the radar when it leaves the factory, including the factory date, serial number and version number.

When the LCD displays the main menu, use  and  to select information item, and press  to enter the menu, LCD display



► Product Date
Serial Number
Version


Use  to move the arrow to product date, serial number, and version, and then press  to view.




2021-01-21






G7200711213



RF:
W802A-001A-20210823
MCU:
W802A-001A-20210823
LCD:
W802/4A-001A-20211013

Schedule:





80G FM Radar Level Meter Commissioning Instructions